



OUTDOOR WOOD CLEANER

Effective cleaning of all wooden surfaces

Woodcare+ Outdoor Wood Cleaner is an effective deep-cleaning agent for all types of wooden surfaces, including decks, garden furniture, fences, eaves, doors, and windows. The product quickly and thoroughly removes dirt and stains, leaving a clean surface that is ideal for further treatment.

- Effectively removes dirt, stains, and grease
- Prepares the wood for further treatment
- Suitable for all types of wood

Application area

Work description

Drying time

Technical data

Always Remember

Always remember to test on a less visible spot to check the compatibility of the surface with the product.

Drying time : 24-48 hours at 20°C

Surface Dry : 24-48 hours at 20°C

Declaration: >5% =15%: Non-ionic surfactants.

Density: 1.00-1.10 g/ml.

pH-value: pH 10-11

Shelf life: 3 years

Application Temperature: +10-25°C, ideally cloudy weather.

Coverage: 15-20 m²/L

Colours: Colourless

Storage: +10-25°C. Keep out of reach of children. Do not expose to heat (e.g. sunlight). Store frost-free during winter and cool during summer.

Packaging sizes: 2.5 L

Odour: Faint

Mixing ratio: 100 ml for 1.0 L water

Maintenance and related products

WOCA Denmark A/S
Tværevej 6
DK - 6640 Lunderskov
+45 9958 5600
info@wocadenmark.com
wocadenmark.com

This information is based on extensive laboratory testing and practical experience. Because the conditions under which the product is used are often beyond the control of WOCA Denmark, we can only guarantee the quality of the actual product. WOCA Denmark A/S accepts no liability for incorrect use and handling of the product. In principle, this product can be considered an intermediate product, as results depend on construction, the nature of the surface, pretreatment, temperature, air humidity, application etc. WOCA Denmark A/S reserves the right to change the product and the stated information without notice. This label/product description replaces all previous versions.